

If your head has 7/16" it will be necessary to enlarge the corresponding holes in the mount to 7/16".

When installing the mount, start all bolts and mount the compressor <u>before</u> tightening. The compressor belt will run in the outer grooves of the crank and water pump pulleys originally used for the factory alternator. It was designed to be used with our 216L driver's side Alternator Mount.

the corresponding holes in the mount to 7/16". (We use a belt length of 58-59" with this mount on installations in our shop. This was determined using GM When installing the mount, start all bolts and mount the compressor before tightening. The compressor belt (Water Pump Pulley.)

As with any part of this nature, make sure it fits your application before painting or plating. Parts that have been painted, plated or modified may not be returned.

A.C.
COMPRESSOR
MOUNT
116R
Bg Block Chevy - Passenger Side
Long Water Pump

ALAN GROVE COMPONENTS, INC. 27070 METCALF ROAD LOUISBURG, KS 66053